


BLAKESLEE DD-60 AND DD-80 ELECTRIC FOOD MIXER 93 TRANSMISSION HOUSING ASSEMBLY



Ref. No.	Item No.	Description						
1	*	Spiral bevel gear and pinion assembly includes 2 and 3	21	97813	Hub gear shift	36	97809	3/8-16 x 1 1/4
			22	70404	Roller	37	97898	Spacer
2	74840	Ferrule and pinion gear	23	99730	Screw shoulder	38	98399	Planetary
3	74840	Ferrule and pinion gear	24	97836	Pin spring	39	97807	Key 1/4 x 1/4 x 4
4	73230	Oil seal shaft	25	97281	Gear wheel	40	97849	Plug-retainer
5	98402	Key	26	97284	Hub			Screw hex head 5/8-18 x 1 1/4
6	97838	Retaining ring	27	98398	Key	41	97832	Cover-planetary
7	97702	Gear bevel support	28	12122	Screw 6/32 x 3/4	42	15310	Screw pan head 8/32 x 3/8
8	7524	Washer 3/8	29	70152	Bowl limit switch			Arrow-direction
9	97858	Screw 3/8-24 x 1 hex head machine	30	14784	Screw hex head 5/16 x 3/4	43	98349	Ring retaining
			30	5996	Washer 5/16	44	97835	Pinion
10	98402	Key	30	70409	Plate-switch mounting bracket	45	97842	Key
11	97816	Shaft main drive				46	98402	Key
12	97824	Roller bearing	30	70411	Weldment-switch	47	97851	Ball bearing
13	99191	Cone-timken	30	10019	Flat washer 5/16	48	97850	Ball bearing
14	99190	Cup-timken	30	14786	Hex nut 5/16	49	97830	Shaft beater
15	73863	Support-transmission	30	70403	Flat washer	50	97857	Pin
16	74170	Transmission	30	14082	Link roller	51	97852	Seal
17	15317	Lock washer 1/2	30	8523	Washer seal	52	98094	Set screw 1/2-20 x 1/2
18	74216	Screw 1/2-13 x 2 hex head cap	31	74215	Nut 5/8"	53	98095	Screw hex head 1/2-20 x 1
19	97826	Knob gear shift	32	74214	Lock washer 5/8			
20	97810	Handle gear shift	33	74213	Screw 5/8-11 x 2 1/4			
			34	97831	Gear planetary			
			35	3574	Screw socket head			

*Note: Please provide model and serial number to order